

ENTREPRISE

logo entreprise

REFLEX FORM - INTERVENTIONS

Before any intervention :

- Please contact the maintenance department of the protected equipment to find out how to proceed.
- Bring a thermal camera: the phenomena detected by E-PREDICT may be imperceptible to humans.
- Please bring the necessary equipment.



Take precautions because an electrical fault has been detected.

HDSN declines all responsibility if the intervention is not carried out in compliance with the legal framework.

IF INDICATOR LIGHT IS GREEN

E-PREDICT is functional, no intervention required.

IF INDICATOR LIGHT IS RED

An alarm is in progress. The intensity of the fault could worsen. Please remedy the fault immediately. Once corrected :

- Restart E-PREDICT, the LED should then return to its normal **FIXED GREEN** state (wait 1 minute), otherwise the problem persists and requires further intervention.

IF INDICATOR LIGHT IS OFF

Status LED is off: E-PREDICT is no longer powered. Check connections and restore power. On restart, the LED will return to its normal **FIXED GREEN** state (wait 1 minute), otherwise the problem persists and requires further action.

IF THE LIGHT IS ORANGE

E-PREDICT is dysfunctional:

1. Switch off E-PREDICT power supply and clean it with a dry air sprayer (fan maintenance procedure).
2. Check that the ambient temperature of the protected equipment does not exceed 70°C.
3. Restart E-PREDICT, the LED should then return to its normal **FIXED GREEN** state (wait 1 minute).

After any intervention:

Send an email to: sav@hdsn.fr mentioning :

- installation number (E-PREDICT)
- LED color
- Fault encountered